

RACER DISPLAY STAND P382



INSTRUCTIONS

- Align hole in metal bracket with indentation on top of base.
- With a hammer, gently tap brass bracket pin through hole in bracket and into oak base (Fig. 1).
- Mark two Xs 4 1/2" apart on the bottom of your PineCar Racer. Insert mounting screws 3/4" of the way into the bottom of your PineCar Racer at the Xs (Fig. 2).
- Press ends of mounting bracket inward, slip under mounting screws on bottom of PineCar Racer and then release (Fig. 2). If bracket is too narrow, spread ends to fit.
- Tighten the mounting screws.

If desired, you can mount an engraved nameplate on the sloping front of the solid oak base.

Add details and accessories to your racer from the complete line of PineCar products. For more products, tips and techniques, see the "Building PineCar Racers" video (P3940 VHS, P3941 DVD), read the "PineCar How To Book" or visit www.pinecar.com.

Scale Model Material



PineCar®

Box 98, Linn Creek, MO 65052

www.pinecar.com

MADE IN USA Z9 ©1994 OCO